

SHENTEK

**Residual *E.coli* DNA
Size Analysis Kit (2G)
User Guide**

Version: A/0

For Research Use Only

Product No.: 1103171-2

Reagents for 4×100 Reactions

Huzhou Shenke Biotechnology Co., Ltd

(*IMPORTANT: Please read this document carefully before experiment.*)

1. Product information

■ Product description

SHENTEK® Residual *E.coli* DNA Size Analysis Kit (2G) is used to quantitate residual *E.coli* DNA of different fragment sizes at various stages of biopharmaceutical products, from in-process samples to final products.

This kit utilizes real-time PCR technique to perform rapid and specific quantitation of residual *E.coli* DNA fragments (FAM) in samples. It is designed to amplify four different fragments (85bp, 103bp, 220bp and 550bp) for the accurate determination of their size distribution at the femtograms (fg) level. For extraction information, please refer to the SHENTEK® Residual Host Cell DNA Sample Preparation Kit User Guide (Product No. 1104191).

■ Kit contents and storage

WARNING: Please read the Material Safety Data Sheets (MSDSs) and follow the handling instructions. Wear appropriate protective eyewear, mask, clothing and gloves.

Table 1. Kit components and storage

Reagent	Part No.	Quantity	Storage
<i>E.coli</i> DNA Control	NNA002	50 µL × 1 tube	-20°C
qPCR Reaction Buffer	NNB001	850 µL × 8 tubes	-20°C, protect from light
<i>E.coli</i> Primer&Probe MIX-85	NNC110	300 µL × 1 tube	
<i>E.coli</i> Primer&Probe MIX-103	NNC111	300 µL × 1 tube	
<i>E.coli</i> Primer&Probe MIX-220	NNC112	300 µL × 1 tube	
<i>E.coli</i> Primer&Probe MIX-550	NNC113	300 µL × 1 tube	
IPC MIX	NNC069	550 µL × 1 tube	
DNA Dilution Buffer (DDB)	NND001	1.5 mL × 3 tubes	-20°C

The kit components can be stored at appropriate conditions for up to 24 months.

Please check the expiration date on the labels.

■ Applied instruments, including but not limited to the following

- SHENTEK-96S Real-Time PCR System
- 7500 Real-Time PCR System
- CFX96 Real-Time PCR System
- LineGene 9600 Real-Time PCR System


■ Required materials not included in the kit

- Nonstick, DNase-free & Low Retention Microfuge Tubes of 1.5 or 2.0 mL
- Nonstick, Low Retention Tips: 1000 μ L, 100 μ L and 10 μ L
- 96-well qPCR plates with sealing film or PCR 8-strip tubes with caps

■ Related equipments

- Real-Time PCR System
- Benchtop microcentrifuge
- Vortex mixer
- Microplate shaker
- Micropipettes: 1000 μ L, 100 μ L and 10 μ L

■ Workflow



2. Methods

■ Experiment preparation

1. Wear appropriate protective eyewear, mask, clothing and gloves.
2. Irradiate the tabletop, micropipettes and tubes with UV for 30 minutes, and disinfect with 75% ethanol.
3. Thaw the kit completely at 2-8°C or melt on ice, vortex and spin briefly.

■ DNA Control serial dilutions for the standard curve

Note: The kit contains four E.coli primer & probe mixes for different fragment lengths. Please set up four separate standard curves corresponding to each fragment length.

Please check the concentration on the label of each tube containing the *E.coli* DNA Control prior to dilution.

Prepare four sets of *E.coli* DNA Control solution with DNA Dilution Buffer (DDB) following the serial dilution procedure below:

1. Thaw *E.coli* DNA Control and DDB completely at 2-8°C or melt on ice. Vortex to mix well and quickly spin down the reagents for 3-5 seconds in microcentrifuge, and repeat 3 times.
2. Label six nonstick 1.5 mL microfuge tubes: ST0, ST1, ST2, ST3, ST4 and ST5.
3. Dilute the DNA Control to 3000 pg/μL with DDB in ST0 tube. Vortex to mix well and quickly spin down the reagents for 3-5 seconds in microcentrifuge, and repeat 3 times to mix thoroughly.
4. Add 180 μL DDB to each tube of ST1, ST2, ST3, ST4 and ST5.
5. Perform the serial dilutions according to Table 2:

Table 2. Dilution for *E.coli* DNA Control

Serial dilution tube	Dilution	Conc. (pg/ μ L)
ST0	Dilute the DNA Control with DDB	3000
ST1	20 μ L ST0 + 180 μ L DDB	300
ST2	20 μ L ST1 + 180 μ L DDB	30
ST3	20 μ L ST2 + 180 μ L DDB	3
ST4	20 μ L ST3 + 180 μ L DDB	0.3
ST5	20 μ L ST4 + 180 μ L DDB	0.03

- *The remaining unused DDB need to be stored at 2-8°C. If the solution is cloudy or contains precipitates, heat at 37°C until it clear.*
- *At least five concentrations of the standard curve should be included. To select appropriate sample dilutions, we recommend performing method validation before sample testing.*

■ Sample preparation

Add 100 μ L of DDB to a new 1.5 mL microfuge tube, and label as NCS.

NCS and samples should be prepared in same way for DNA extraction.

■ qPCR MIX preparation

1. Determine the number of reaction wells based on your selected standard curve, with the number of test samples and control samples. Generally, triplicates are tested for each sample.

$$\text{Number of reaction wells} = (\text{standard curve of 5 concentration gradients} + 1 \text{ NTC} + 1 \text{ NCS} + \text{test samples}) \times 3$$

2. Prepare qPCR MIX according to Table 3, 4, 5 and 6.

Table 3. qPCR MIX-85 preparation

Reagents	Volume/reaction	Volume for 30 reaction (includes 10% overage)
qPCR Reaction Buffer	15.9 μ L	524.7 μ L
<i>E.coli</i> Primer&Probe MIX-85	2.8 μ L	92.4 μ L
IPC MIX	1.3 μ L	42.9 μ L
Total volume	20 μ L	660 μ L

Table 4. qPCR MIX-103 preparation

Reagents	Volume/reaction	Volume for 30 reaction (includes 10% overage)
qPCR Reaction Buffer	15.9 μ L	524.7 μ L
<i>E.coli</i> Primer&Probe MIX-103	2.8 μ L	92.4 μ L
IPC MIX	1.3 μ L	42.9 μ L
Total volume	20 μ L	660 μ L

Table 5. qPCR MIX-220 preparation

Reagents	Volume/reaction	Volume for 30 reaction (includes 10% overage)
qPCR Reaction Buffer	15.9 μ L	524.7 μ L
<i>E.coli</i> Primer&Probe MIX-220	2.8 μ L	92.4 μ L
IPC MIX	1.3 μ L	42.9 μ L
Total volume	20 μ L	660 μ L

Table 6. qPCR MIX-550 preparation

Reagents	Volume/reaction	Volume for 30 reaction (includes 10% overage)
qPCR Reaction Buffer	15.9 μ L	524.7 μ L
<i>E.coli</i> Primer&Probe MIX-550	2.8 μ L	92.4 μ L
IPC MIX	1.3 μ L	42.9 μ L
Total volume	20 μ L	660 μ L

For simultaneous detection of the four fragments, please prepare at least 120 μ L template DNA for four assays. We recommend to prepare 2 tubes of each sample for pre-treatment at the same time and pool them after extraction.

3. Mix thoroughly and place on ice, aliquot 20 μL /well into 96-well qPCR plate or PCR 8-strip tubes.

■ qPCR Reaction MIX preparation

1. Prepare qPCR Reaction MIX following Table 7-10, and a 96-well plate layout template is shown in Table 11.

Table 7. qPCR Reaction MIX-85 preparation

Tubes	ST-85	NTC	NCS	Test sample
qPCR MIX-85	20 μL	20 μL	20 μL	20 μL
Samples	10 μL ST1 - ST5	10 μL DDB	10 μL purified NCS	10 μL purified test sample
Total Volume	30 μL	30 μL	30 μL	30 μL

Table 8. qPCR Reaction MIX-103 preparation

Tubes	ST-103	NTC	NCS	Test sample
qPCR MIX-103	20 μL	20 μL	20 μL	20 μL
Samples	10 μL ST1 - ST5	10 μL DDB	10 μL purified NCS	10 μL purified test sample
Total Volume	30 μL	30 μL	30 μL	30 μL

Table 9. qPCR Reaction MIX-220 preparation

Tubes	ST-220	NTC	NCS	Test sample
qPCR MIX-220	20 μL	20 μL	20 μL	20 μL
Samples	10 μL ST1 - ST5	10 μL DDB	10 μL purified NCS	10 μL purified test sample
Total Volume	30 μL	30 μL	30 μL	30 μL

Table 10. qPCR Reaction MIX-550 Preparation

Tubes	ST-550	NTC	NCS	Test sample
qPCR MIX-550	20 μL	20 μL	20 μL	20 μL
Samples	10 μL ST1 - ST5	10 μL DDB	10 μL purified NCS	10 μL purified test sample
Total Volume	30 μL	30 μL	30 μL	30 μL

Table 11. Example of 96-well plate layout

MIX-85			MIX-103			MIX-220			MIX-550			
NTC	NTC	NTC	NTC	NTC	NTC	NTC	NTC	NTC	NTC	NTC	NTC	A
NCS	NCS	NCS	NCS	NCS	NCS	NCS	NCS	NCS	NCS	NCS	NCS	B
S	S	S	S	S	S	S	S	S	S	S	S	C
ST5	ST5	ST5	ST5	ST5	ST5	ST5	ST5	ST5	ST5	ST5	ST5	D
ST4	ST4	ST4	ST4	ST4	ST4	ST4	ST4	ST4	ST4	ST4	ST4	E
ST3	ST3	ST3	ST3	ST3	ST3	ST3	ST3	ST3	ST3	ST3	ST3	F
ST2	ST2	ST2	ST2	ST2	ST2	ST2	ST2	ST2	ST2	ST2	ST2	G
ST1	ST1	ST1	ST1	ST1	ST1	ST1	ST1	ST1	ST1	ST1	ST1	H
1	2	3	4	5	6	7	8	9	10	11	12	

- *This example represents four assays, including selected standard curve points of E.coli DNA Control (ST1-ST5), 1 NTC, 1 NCS and 1 test sample, with 3 replicates for each sample.*
- *The plate layout for sample loading can be adjusted based on the sample quantity.*

2. Seal the 96-well plate with sealing film. Mix well in microplate shaker, then spin down the reagents for 10 seconds in centrifuge and place it on the qPCR instrument.

■ qPCR program setting

NOTE: The following instructions apply only to the ABI7500 instrument with SDS v1.4. If you use a different instrument or software, refer to the applicable instrument or software documentation.

1. Create a new document, then in the Assay drop-down list, select **Standard Curve (Absolute Quantitation)**.
2. Click **New Detector**, then enter *E.coli-85* in the Name field, select **FAM** in the Reporter Dye drop-down list and select **(none)** in the Quencher Dye drop-down list, then click **OK**.
3. Create new detector for *E.coli-103*, *E.coli-220* and *E.coli-550*, separately as step2.

4. Click **New Detector**, then enter IPC in the Name field. Select **VIC** in the Reporter Dye drop-down list and select **(none)** in the Quencher Dye drop-down list, then click **OK**.
5. Select **ROX** as the passive reference dye, then Click **Next**.
6. Select the applicable set of wells for the samples, then select the corresponding detector for each well.
7. Select Finish, and then set thermal-cycling conditions:
 - a. Set the thermal cycling reaction volume to 30 μL .
 - b. Set the temperature and time as follow in Table 12:

Table 12. qPCR running temperature and time

Step	Temp.	Time(mm:sec)	Cycles
Activation	95°C	10:00	1
Denaturation	95°C	00:15	40
Annealing	60°C	00:30	
Extension	72°C*	01:30	

*Instrument will read the fluorescence signal during this step.


8. Save the document, then click **Start** to start the qPCR run.

■ Results analysis

1. Select **Set up** tab, then set tasks for each sample type by clicking on the Task Column drop-down list:
 - a. NTC: target DNA detector task = **NTC**
 - b. NCS, test samples= **Unknown**
2. Set up the standard curve as shown in the following table 13.

Table 13. Settings for Standard curve

Tube label	Task	Quantity (pg/ μ L)
ST1	Standard	300
ST2	Standard	30
ST3	Standard	3
ST4	Standard	0.3
ST5	Standard	0.03

3. Select the **Results** tab, then select Amplification Plot.
4. In the Data drop-down list, select **Delta Rn vs Cycle**.
5. In the Analysis Settings window, enter the following settings :
 - a. Select **Manual Ct**.
 - b. In the Threshold field, enter 0.02.
 - c. Select **Automatic Baseline**.
6. Click the button  in the toolbar, then wait the plate analyzing.
7. Select the **Result** tab > **Standard curve** tab, then verify the Slope, Intercept and R² values .
8. Select the Report tab, then achieve the mean quantity and standard deviation for each sample.
9. Select **File** > **Export** > **Results**. In the Save as type drop-down list, select **Results Export Files**, then click **Save**.

Note: The parameter settings of the result analysis should be based on the specific model and the software version, and generally can also be automatically interpreted by the instrument.

10. Set the value of DNA size-85 to be 100%, calculate the percentage of the DNA size of 103, 220 and 550.
11. Analyze the Ct value of IPC. Normally, the mean Ct-IPC value of the sample should be within ± 1.0 of the NCS Ct-IPC value. If the mean Ct-IPC value of the sample is significantly higher than the Ct-IPC value of the NCS, this indicates that the sample may be inhibitory to the assay. We recommend to

test the ERC samples in the same assay, and take the sample recovery rate result as the criterion.

12. The Ct value of NTC and NCS should be larger than the mean Ct value of the lowest standard curve concentration or no significant peaks shown in the amplification curve, meanwhile performs normal amplification curve in the VIC signal channel.

Effective date: 28 Jun. 2024

Support & Contact

The logo for SHENTEK, with 'SHEN' in blue and 'TEK' in green.

Huzhou Shenke Biotechnology Co., Ltd.

www.shentekbio.com

Address: 8th Floor, 6B Building, No.1366 Hongfeng Road, Huzhou313000, Zhejiang Province, China

E-mail: info@shentekbio.com

Phone: +1 (908) 822-3199 / (+86) 400-878-2189